BLUETOOTH WIRELESS STEREO SPEAKER WOOMBOX USER MANUAL

PLEASE READ THIS USER MANUAL COMPLETELY BEFORE OPERATING THIS UNIT AND RETAIN THIS BOOKLET FOR FUTURE REFERENCE.

IMPORTANT SAFETY INSTRUCTIONS

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference.

Take special note of all warnings listed in these instructions and on the unit.

1. Read these instructions – All the safety and operating instructions should be read before the appliance is operated.
2. Keep these instructions – The safety and operating instructions should be kept for future reference.
3. Heed all warnings – All warnings on the appliance and in the operating instructions should be adhered to.
4. Follow all instructions – All operation and use instructions should be followed.
5. Do not use this apparatus near water – The appliance should not be used near water; for example, near a bath tub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool.
6. Clean only with dry cloth – The appliance should be cleaned only as recommended by the manufacturer.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings; or placed in a built-in installation, such as a bookcase or cabinet that may impede the flow of air through the ventilation openings.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Only use attachments / accessories specified by the manufacturer.
10. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
11. This appliance shall not be exposed to dripping or splashing water and that no object filled with liquids such as vases shall be placed on the apparatus.
12. Power Sources – The appliance should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance. Do not overload wall outlet.
13. Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
14. There is a high energy rechargeable battery inside the speaker box, do not throw it into fire to avoid danger of explosion.
15. Do not charge the internal rechargeable battery longer than specified to prevent danger of fire. Overcharging rechargeable batteries may shorten their life span.
16. Do not attempt to dismantle, open or repair this product yourself. If a fault occurs, seek advice from your local qualified service technician or contact the distributor.

IMPORTANT NOTES

Avoid installing the unit in locations described below:

- Places exposed to direct sunlight or close to heat radiating appliances such as electric heaters.
- Places subject to constant vibration.
- Dusty, humid or moist places.

NOTE: This product is not magnetically shielded and may cause color distortion on the screen of some TVs or video monitors. To avoid this, you may need to move the unit further away from the TV or monitor if unnatural color shifts or image distortion occurs.

COMPLIANCE WITH FCC REGULATIONS

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

PROTECT YOUR FURNITURE

This model is equipped with non-skid rubber 'feet' to prevent the product from moving when you operate the controls.These 'feet' are made from non-migrating rubber material specially formulated to avoid leaving any marks or stains on your furniture. However certain types of oil based furniture polishes, wood preservatives, or cleaning sprays may cause the rubber 'feet' to soften, and leave marks or a rubber residue on the furniture. To prevent any damage to your furniture we strongly recommend that you purchase small self-adhesive felt pads, available at hardware stores and home improvement centers everywhere, and apply these pads to the bottom of the rubber 'feet' before you place the product on fine wooden furniture.

PRODUCT FEATURES

The WOOMBOX is a Bluetooth portable stereo speaker with the following features:

- Auxiliary input jack to play music from your iPod or digital audio player
- Wireless playback of music from your mobile phone via the Bluetooth connection
- Up to 33 feet (10 meters) operating range
- Digital volume control
- Built-in 1,000 mAh Li-Polymer rechargeable battery.

LOCATION OF CONTROLS





1. **VOLUME DOWN (-) BUTTON**
2. **POWER ⏻ ON/OFF BUTTON; POWER/CHARGING INDICATOR**
3. **BLUETOOTH ON/OFF BUTTON; BLUETOOTH STATUS INDICATOR**
4. **VOLUME UP (+) BUTTON**
5. **SPEAKER**
6. **AUX-IN JACK**
7. **DC IN/BATTERY CHARGING JACK**
8. **CONDENSOR MIC**

LED STATUS INDICATORS

LED Position	Description	LED Status
Power Indicator	No Power	LED Off
	Power on	Slow Flashing Green
	Low Battery	Fast Flashing Red
Charging Indicator (Power On Mode)	On and working	Slow Flashing Green and Red
	Low Battery	Fast Flashing Red
	Battery Full	Solid Green and Red
Charging Indicator (Power Off Mode)	No charging	Red LED Off
	Charging	Slow Flashing Red
	Charging Finished	Solid Red
Bluetooth Status Indicator	Off	LED Off
	Ready to Link	Blue & Red LED flash alternatively
	Not linked	Blue LED flash 2 times per second
	Linked	Blue LED flash every 4 seconds
	Low Battery	Red LED quick flash 2 times every 30 seconds

Remarks:

Fast Flashing - less than 1 second apart.

Slow Flashing - around 3 - 4 seconds apart

CHARGING INSTRUCTIONS

This unit operates on a built-in Li-Polymer battery that can be recharged either using the USB port on your computer or from a USB power adaptor (not included) with a rated output of DC 5V, 1000mA.

Note: The DC input jack located on this unit is mainly designed for charging the built-in Li-Polymer battery. The unit will still operate normally while charging, but doing this may reduce the battery life.

CHARGING THE BATTERY

1. Charge the built-in Li-Polymer battery a minimum of 4 hours prior to first use. Plug the unit into a USB port on your computer or into a USB power adaptor (not included) using the included USB cable.

2. Unplug the USB cable from the power source once the battery is fully charged.

3. After prolonged use, the battery voltage may discharge and operation might become intermittent. When the internal battery charge is very low, the Red power button backlight will begin flashing alerting you to recharge the internal battery.

⚠ Battery Note and Care

1: Do not burn or bury batteries.

2: Do not puncture or crush.

3: Do not disassemble.

4: Recycle Li-Polymer batteries. Do not dispose of in the trash.

5: Use only chargers rated for Li-Polymer cells. Be sure the charger's voltage and current settings are correct for the battery pack being charged.

6: Charge batteries on a fireproof surface away from flammable items or liquids.

7: Batteries should NEVER be left unattended while charging. Only adults should charge the batteries.

8: Follow the manufacturer's instructions for charging the product and do not charge longer than recommended. Unplug the charger when the battery is charged or not used.

TURNING THE SPEAKER POWER ON/OFF

1. In standby mode, tap the POWER button to turn on the unit, the power button backlight will light up green and begin blinking slowly.

2. In power on mode, tap the POWER button to turn the unit off, the green power button backlight turns off.
   Note: Before first use, please charge the speakers for at least 4 hours because the batteries may not fully charged, even though the charging LED lights.

BLUETOOTH OPERATION

Power on the unit and follow the directions below to use the A2DP profile Bluetooth features of this unit.

Turn on the Bluetooth

In Bluetooth Off mode, press and hold the Bluetooth button for about 5 seconds until a beep sound is heard and the Bluetooth button backlight flashes blue.

Note: Press and hold the Bluetooth button for about 9 seconds to change to Bluetooth pairing (linking) mode. The Bluetooth button backlight will flash blue and red.

Turn off the Bluetooth

In Bluetooth ON mode, press and hold the Bluetooth button and hold for about 3 seconds until a beep sound is heard and the Bluetooth button backlight flashes red and then all lights go off.

PAIRING (LINKING) A BLUETOOTH ENABLED MOBILE PHONE OR OTHER BLUETOOTH ENABLED DEVICE TO THE WOOMBOX

1. With the power on and Bluetooth Off , press and hold the Bluetooth button for about 9 seconds until a second beep sound is heard, The Bluetooth button backlight will flash blue and red. The WOOMBOX is ready to pair (link) with your Bluetooth device.
2. Turn on the Bluetooth feature of your mobile phone and enable the search or scan feature to find the WOOMBOX.
3. Select "WOOMBOX" from the device list when it appears on your screen. If required, enter the pass code “0000” to pair (link) the WOOMBOX with your mobile phone.
4. After successfully pairing (linking) your mobile phone with the WOOMBOX, you can play music from your mobile phone wirelessly to the WOOMBOX.

5. Press the Volume Up (+) / Down (-) button to adjust the desired volume level.
6. To turn off the WOOMBOX Bluetooth, press and hold the Bluetooth button for about 3 seconds until a beep sound is heard and the Bluetooth button backlight flashes red and then all lights go off. Don't forget to also turn off the Bluetooth feature on your mobile phone.

Notes:

1. Refer to manual of your mobile phones, iPad, computer or other Bluetooth enabled device for Bluetooth operation, since it may vary from model to model. Your Bluetooth enabled device will not play the music through the speaker, even it can be connected, if the device does not support A2DP.
2. If the built in Li-Polymer battery reaches a very low power level that affects Bluetooth operation, The Bluetooth button backlight indicator will begin to rapidly blink red two times every 30 seconds before it turns off. Three gong type sounds will be heard prior to the WOOMBOX turning off. This will alert you to recharge the speaker battery immediately.
3. Do not plug in the Audio jack when the Bluetooth is in operation.
4. If you are pairing (linking) your computer to the WOOMBOX using Bluetooth, you may need to set the WOOMBOX as your computer's default sound device.

Using the WOOMBOX as a Hands Free Bluetooth Speakerphone

1. Link your mobile phone to the speaker via Bluetooth as described above.
2. When receiving an incoming call on your mobile phone, tap the Bluetooth button on the WOOMBOX to switch an incoming call from mobile phone to the WOOMBOX. A short beep sound will be heard confirming the call was answered. Complete your call using the built-in microphone and speaker of the WOOMBOX.
3. Press the VOLUME UP(+) /DOWN (-) button on the WOOMBOX to adjust the volume to your desired sound level.
4. To end the call, just tap the Bluetooth button again on the WOOMBOX. A short beep sound will be heard and the call will end. If you were streaming music from your mobile phone to the WOOMBOX, the music will automatically resume streaming to the WOOMBOX.
5. To reject an income-call, simply press and hold the Bluetooth button on the WOOMBOX for about 2 seconds, a long beep sound will be heard.

NOTE:
If you press and hold the Bluetooth button for about 3 seconds, it will turn off the Bluetooth of the WOOMBOX.

Redialing the last number with the WOOMBOX

The WOOMBOX will automatically redial the last number you dialed by tapping the WOOMBOX Bluetooth button twice.

Hang up with the WOOMBOX

A quick press on the Bluetooth button will end the call in progress. A short beep tone will be heard from the WOOMBOX confirming the call ended.

Re-linking to the mobile phone

If your mobile phone is already paired with the WOOMBOX, but became unlinked even with both Bluetooth devices turned on. You can re-link them by:

1. Turn off the WOOMBOX Bluetooth and turn it on again to re-link your mobile phone. The red Bluetooth button status indicator will blink two times with two short beeps if the WOOMBOX and your mobile phone have been re-linked successfully.

2. You can also re-link the WOOMBOX by using Bluetooth operation of your mobile phone. Please refer to operation manual of your mobile phone for more information.

PLAYING MUSIC USING THE AUXILIARY INPUT

The WOOMBOX features an auxiliary audio signal input jack for connecting external audio devices like MP3 players, CD players, iPhones or iPods (except iPod shuffle 3rd gen) and listen to the through the speakers of the WOOMBOX.

1. Use the audio cable (included) with one 3.5 mm stereo plug on each end of the cable.
2. Plug one end into the AUX-IN jack on the WOOMBOX and the other end of the cable into the Line-out Jack or Headphone Jack of your external audio device.
3. Tap the POWER ⏻ button to turn on the WOOMBOX. The POWER button backlight will turn green and begin flashing slowly.
4. Turn on your external audio device.
5. Press the VOLUME UP (+) / DOWN (-) button to adjust the desired volume level. Operate all other functions on the auxiliary device as usual.

NOTES:

(1). If you're connected to the Line Out Jack of your external device then you only need to adjust the volume control on the WOOMBOX. If you're connected to the Headphone Jack of your external device, then you may need to adjust both the volume control of your external device and the volume control on the WOOMBOX to find the most desirable volume setting.

(2). If you use AUX IN function in Bluetooth on mode, Bluetooth audio will be temporarily disconnected when the audio cable plugged in. Unplugging the audio cable will resume Bluetooth audio. We suggest you turn off the Bluetooth to save battery power when playing music via AUX IN mode.

(3). Tap the POWER ⏻ button to turning off the system when you finish listening. Don't forget to switch off the power of your external device as well.

RECHARGING WOOMBOX BATTERY

When you listen to music, the built-in rechargeable Li-Polymer battery will eventually reach a low power condition. The power indicator will turn red and start flashing quickly, so please charge the speaker battery as soon as possible.

1. Plug the unit into a USB port on your computer or into a DC 5V, 1000mA USB power adaptor (not included) using the included USB cable.

2. Plug the DC plug of the cable into the WOOMBOX.

Charging in Power On mode

- The Red LED flashes quickly every second if battery is still at a low level.
- The Green LED will turn on and the Red LED slowly flashes Green simultaneously if battery is charged up to a workable level.
- Both Green & Red LED lit solid if battery is fully charged.

Charging in Unit Power Off mode

- The Red LED turns on and starts flashing slowly.
- The Red LED lights solid when the battery is fully charged after charging for about 4 hours.

NOTES:

1. Charging time will vary if you are listening to music while charging the speaker battery. We recommend you switch off the speaker power during the charging process or until the speaker batteries are fully charged.

2. To prolong the life of a rechargeable battery, it is recommended to completely discharge it before fully charging it again.

3. Rechargeable batteries need to be cycled for maximum performance and longer battery life. If you don't use the player that often, be sure to recharge the battery at least once a month in order to keep the internal battery working properly.

Remarks:

- Quick flashing implies the LED lights up for 1 second and shuts off for 1 second.
- Slow flashing implies the LED lights up for 4 seconds and shuts off for 4 seconds.

CARE AND MAINTENANCE

1. Avoid operating your unit under direct sunlight or in hot, humid or dusty places.
2. Keep your unit away from heating appliances and sources of electrical noise such as fluorescent lamps or motors.
3. Unplug the unit from the electrical power outlet immediately in case of malfunction.

CLEANING THE UNIT

- To prevent fire or shock hazard, disconnect your unit from the USB port of power source when cleaning.
- The finish on the unit may be cleaned with a dust cloth and cared for as other furniture, Use caution when cleaning and wiping the plastic parts.
- If the cabinet becomes dusty wipe it with a soft dry dust cloth. Do not use any wax or polish sprays on the cabinet.
- If the front panel becomes dirty or smudged with fingerprints it may be cleaned with a soft cloth slightly dampened with a mild soap and water solution. Never use abrasive cloths or polishes as these will damage the finish of your unit.

CAUTION: Never allow any water or other liquids to get inside the unit while cleaning

TROUBLESHOOTING GUIDE

Symptom	Possible Problem	Solution
No Charging	AC Adaptor is not plugged into a wall outlet or the connector is not plugged into the power supply jack on the back of the unit.	Plug the AC adaptor into a wall outlet and plug the connector into the supply jack on the unit.
	Wall outlet is not functioning.	Plug another device into the same outlet to confirm the outlet is working.
	Computer USB port is not functioning.	Make sure your computer power is turned on and try another USB port.
No Sound	Speaker batteries are dead	Recharge the speaker batteries
	Bluetooth speaker is not linked with the mobile phone	Go through “Bluetooth Operations” process to link the speakers.
	Speaker placement out of range	Relocate the speaker within Bluetooth operating range
	Volume set too low	Press the Volume+ button to turn the sound level up.
Sound is distorted.	Volume level is set too high.	Decrease the volume.
	Sound source is distorted.	If the mobile-phone original sound source is of poor quality, distortion and noise are easily noticed with high-power speakers. Try a different audio source such as a music CD.
		If you are using an external sound source like older generation of iPod, try reducing the output volume on the device itself. Also try turning bass boost OFF or change the EQ setting.
Unit gets warm after extended play at high volume.	This is normal.	Turn the unit off for a period of time or lower volume.

SPECIFICATIONS

Bluetooth : v 2.1
Wireless Receiving Distance : 10M / 33FT
Bluetooth Profiles : A2DP , HFP , HSP
Advanced Audio Distribution Profile (A2DP) for wireless music streaming.
Hands-Free (HFP) and Headset Profiles (HSP) for Hands-Free speakerphone.
Hangs-Free Speaker for Bluetooth phone.
Built-in Microphone.
Audio Input : AUX-IN 3.5mm. Connect your iPod, MP3, Digital Audio Player.
Audio Cable included.
Audio Output Power : 1.25W (RMS) X 2
Impedance: 4 Ohm
Sensitivity: 76dB
THD: < 1%
Audio Frequency Response : 150Hz – 20KHz
Digital Volume Control.
Built-in Rechargeable 1000mAh Battery.
USB charge cable included.
DC IN : 5V / 1000mA
6-10 Hours of continuous playback
Material : Aluminum Alloy
Dimension: 14.5(W) x 5.7(H) x 3.2(D) cm
Weight : 220g
Carry Pouch included

Bluetooth® is a registered trademark of Bluetooth SIG, Inc